2-wire Modular VTO (Version 3.1) User's Manual

Cybersecurity Recommendations

Mandatory actions to be taken towards cybersecurity

1. Change Passwords and Use Strong Passwords:

The number one reason systems get "hacked" is due to having weak or default passwords. It is recommended to change default passwords immediately and choose a strong password whenever possible. A strong password should be made up of at least 8 characters and a combination of special characters, numbers, and upper and lower case letters.

2. Update Firmware

As is standard procedure in the tech-industry, we recommend keeping NVR, DVR, and IP camera firmware up-to-date to ensure the system is current with the latest security patches and fixes.

"Nice to have" recommendations to improve your network security

1. Change Passwords Regularly

Regularly change the credentials to your devices to help ensure that only authorized users are able to access the system.

2. Change Default HTTP and TCP Ports:

- Change default HTTP and TCP ports for systems. These are the two ports used to communicate and to view video feeds remotely.
- These ports can be changed to any set of numbers between 1025-65535. Avoiding the default ports reduces the risk of outsiders being able to guess which ports you are using.

3. Enable HTTPS/SSL:

Set up an SSL Certificate to enable HTTPS. This will encrypt all communication between your devices and recorder.

4. Enable IP Filter:

Enabling your IP filter will prevent everyone, except those with specified IP addresses, from accessing the system.

5. Change ONVIF Password:

On older IP Camera firmware, the ONVIF password does not change when you change the system's credentials. You will need to either update the camera's firmware to the latest revision or manually change the ONVIF password.

6. Forward Only Ports You Need:

- Only forward the HTTP and TCP ports that you need to use. Do not forward a huge range of numbers to the device. Do not DMZ the device's IP address.
- You do not need to forward any ports for individual cameras if they are all connected to a recorder on site; just the NVR is needed.

7. Disable Auto-Login on SmartPSS:

Those using SmartPSS to view their system and on a computer that is used by multiple people should disable auto-login. This adds a layer of security to prevent users without the appropriate credentials from accessing the system.

8. Use a Different Username and Password for SmartPSS:

In the event that your social media, bank, email, etc. account is compromised, you would not want someone collecting those passwords and trying them out on your video surveillance system. Using a different username and password for your security system will make it more difficult for someone to guess their way into your system.

9. Limit Features of Guest Accounts:

If your system is set up for multiple users, ensure that each user only has rights to features and functions they need to use to perform their job.

10. UPnP:

- UPnP will automatically try to forward ports in your router or modem. Normally this would be a good thing. However, if your system automatically forwards the ports and you leave the credentials defaulted, you may end up with unwanted visitors.
- If you manually forwarded the HTTP and TCP ports in your router/modem, this feature should be turned off regardless. Disabling UPnP is recommended when the function is not used in real applications.

11. SNMP:

Disable SNMP if you are not using it. If you are using SNMP, you should do so only temporarily, for tracing and testing purposes only.

12. Multicast:

Multicast is used to share video streams between two recorders. Currently there are no known issues involving Multicast, but if you are not using this feature, deactivation can enhance your network security.

13. Check the Log:

If you suspect that someone has gained unauthorized access to your system, you can check the system log. The system log will show you which IP addresses were used to login to your system and what was accessed.

14. Physically Lock Down the Device:

Ideally, you want to prevent any unauthorized physical access to your system. The best way to achieve this is to install the recorder in a lockbox, locking server rack, or in a room that is behind a lock and key.

15. Connect IP Cameras to the PoE Ports on the Back of an NVR:

Cameras connected to the PoE ports on the back of an NVR are isolated from the outside world and cannot be accessed directly.

16. Isolate NVR and IP Camera Network

The network your NVR and IP camera resides on should not be the same network as your public computer network. This will prevent any visitors or unwanted guests from getting access to the same network the security system needs in order to function properly.

General

This document mainly introduces product function, structure, networking, mounting process, debugging process, WEB operation and technical parameters of 2-wire Modular VTO, which is matched with Version 3.12 WEB interface.

Models

VTO2000A-C-2, VTO2000A-B, VTO2000A-K, VTO2000A-R and VTO2000A-F.

Device Upgrade

Please don't cut off power supply during device upgrade. Power supply can be cut off only after the device has completed upgrade and has rebooted.

General Description about Keys

- OK: it is used to save the settings.
- Default: it is used to restore all parameters at the present interface to default system configurations.
- Refresh: restore parameters at the present interface to present system configurations.

Safety Instructions

The following categorized signal words with defined meaning might appear in the Manual.

Signal Words	Meaning
A DANGER	Indicates a high potential hazard which, if not avoided, will result in death or serious injury.
WARNING	Indicates a medium or low potential hazard which, if not avoided, could result in slight or moderate injury.
A CAUTION	Indicates a potential risk which, if not avoided, could result in property damage, data loss, lower performance, or unpredictable result.
©T TIPS	Provides methods to help you solve a problem or save you time.
NOTE	Provides additional information as the emphasis and supplement to the text.

Revision History

No.	Version No.	Revision Content	Release Date
1	V1.0.0	First release	October 2017
2	V1.0.1	Add privacy protection notice	May 2018
3	V1.0.2	Change Figure 3-1, 3-2 and 3-3	November 2018

Privacy Protection Notice

As the device user or data controller, you might collect personal data of others, such as face, fingerprints, car plate number, Email address, phone number, GPS and so on. You need to be in compliance with the local privacy protection laws and regulations to protect the legitimate rights and interests of other people by implementing measures, including but not limited to: providing clear and visible identification to inform data subject the existence of surveillance area and providing related contact.

About the Manual

- The Manual is for reference only. If there is inconsistency between the Manual and the actual product, the actual product shall prevail.
- We are not liable for any loss caused by the operations that do not comply with the Manual.
- The Manual would be updated according to the latest laws and regulations of related regions. For detailed information, see the paper User's Manual, CD-ROM, QR code or our official website. If there is inconsistency between paper User's Manual and the electronic version, the electronic version shall prevail.
- All the designs and software are subject to change without prior written notice. The product updates might cause some differences between the actual product and the Manual. Please contact the customer service for the latest program and supplementary documentation.
- There still might be deviation in technical data, functions and operations description, or errors in print. If there is any doubt or dispute, please refer to our final explanation.
- Upgrade the reader software or try other mainstream reader software if the Guide (in PDF format) cannot be opened.
- All trademarks, registered trademarks and the company names in the Manual are the properties of their respective owners.
- Please visit our website, contact the supplier or customer service if there is any problem occurred when using the device.
- If there is any uncertainty or controversy, please refer to our final explanation.

Important Safeguards and Warnings

The following description is the correct application method of the device. Please read the manual carefully before use, in order to prevent danger and property loss. Strictly conform to the manual during application and keep it properly after reading.

Operating Requirement

- Please don't place and install the device in an area exposed to direct sunlight or near heat generating device.
- Please don't install the device in a humid, dusty or fuliginous area.
- Please keep its horizontal installation, or install it at stable places, and prevent it from falling.
- Please don't drip or splash liquids onto the device; don't put on the device anything filled with liquids, in order to prevent liquids from flowing into the device.
- Please install the device at well-ventilated places; don't block its ventilation opening.
- Use the device only within rated input and output range.
- Please don't dismantle the device arbitrarily.
- Please transport, use and store the device within allowed humidity and temperature range.

Power Requirement

- The product shall use electric wires (power wires) recommended by this area, which shall be used within its rated specification!
- Please use power supply that meets SELV (safety extra low voltage) requirements, and supply power with rated voltage that conforms to Limited Power Source in IEC60950-1. For specific power supply requirements, please refer to device labels.
- Appliance coupler is a disconnecting device. During normal use, please keep an angle that facilitates operation.

Table of Contents

	Cybersecurity Recommendations	
	Foreword	
	Important Safeguards and Warnings	
1	Product Overview	
	1.1 Product Profile	
_	1.2 Product Function	
2		
	2.1 Camera Module	
	2.2 Button Module	
	2.3 Keyboard Module (with Braille)	
	2.4 Card Swiping Module	
	2.5 Fingerprint Module	
	2.7 Networking Diagram	
3		
3	3.1 One-to-one Scene.	
	3.2 One-to-many Scene	
	3.3 Group Call Scene	
4	·	
•	4.1 Surface Mounting	
	4.2 Flush Mounting	
5	C .	
	5.1 Debugging Settings	
	5.1.1 VTO Settings	
	5.1.2 VTH Settings (Version 3.1)	
	5.1.3 VTH Settings (Version 4.0)	
	5.2 Debugging Verification	
	5.2.1 Verification with Version 3.1 VTH	
	5.2.2 Verification with Version 4.0 VTH	
6	Basic Function	
	6.1 Call Function	
	6.1.1 Call Management Centre	37
	6.1.2 Single Call of VTH	38
	6.1.3 Group Call	40
	6.2 Unlock Function	42
	6.2.1 Remote Unlock at VTH/VTS	42
	6.2.2 Open Door at WEB Interface	42
	6.2.3 Unlock with IC Card	43
	6.2.4 Unlock with Exit Button	43
	6.2.5 Unlock with Password	43
	6.3 Issue Card	44

6.4 Monitoring Function	45
6.5 Tamper Switch	46
6.6 Restore Backup	46
7 WEB Config	48
7.1 Initialization	48
7.2 Reset the Password	49
7.3 System Login	51
7.4 User Manager	52
7.4.1 Add User	52
7.4.2 Modify User	53
7.4.3 Delete User	55
7.5 Network Parameter Config	55
7.5.1 Network Config	55
7.5.2 FTP Server	56
7.5.3 Port	56
7.5.4 DDNS Server	58
7.5.5 P2P	59
7.5.6 HTTPS Setting	59
7.5.7 UPnP	60
7.5.8 IP Purview	62
7.6 LAN Config	63
7.7 Local Parameter Config	65
7.7.1 Local Config	65
7.7.2 Facade Layout	66
7.7.3 Access Manager	68
7.7.4 Sound Control	70
7.7.5 Talk Manager	70
7.7.6 System Time	71
7.7.7 Config Manager	72
7.8 Indoor Manager	73
7.8.1 Add VTH	73
7.8.2 Modify VTH	74
7.8.3 Delete VTH	74
7.8.4 QR Code	74
7.8.5 Config Manager	75
7.8.6 Card Manager	76
7.9 Video Set	77
7.9.1 Video Set	77
7.9.2 Audio Set	79
7.10 IPC Info	
7.10.1 Add One IPC	79
7.10.2 Delete	
7.10.3 Batch Import	
7.10.4 Batch Export	
7.11 Fingerprint Manager	
7.11.1 Collect Fingerprint	
7.11.2 Modify Fingerprint Info	82

7.11.3 Remove Fingerprint	82
7.11.4 Import Fingerprint Info	82
7.11.5 Export Fingerprint Info	82
7.12 Info Search	83
7.12.1 Call History	83
7.12.2 Alarm Record	83
7.12.3 Unlock Record	84
7.13 Reboot Device	84
7.14 Logout	84
8 FAQ	86
Appendix 1 Technical Parameters	87
Appendix 1.1 VTO2000A-C-2	87
Appendix 1.2 VTO2000A-B/VTO2000A-K/VTO2000A-R /VTO2000A-F	88
Appendix 2 Accessory Specification	89
Appendix 2.1 Specification of Network Cable	89
Appendix 2.2 Specification of Extension Power Cord	
Appendix 2.3 Specification of Embedded Box	89

Product Overview

1.1 Product Profile

2-wire Modular VTO consists of camera module, one-button module, three-button module, five-button module, keyboard module, card swiping module and fingerprint module. Camera module is indispensable, whereas other modules can be matched flexibly, and can combine with VTH, VTS and platform to establish a video intercom system. Support video call between a visitor and a resident, group call, emergency call, unlock, info sending, video preview and record search. It is mainly applied in apartments and villas, and matched with management platform to realize all-round anti-theft, disaster prevention and monitoring function.

1.2 Product Function

Video Intercom

Call VTH users and realize video talk.

Group Call

Call multiple VTH users at one VTO simultaneously.

Be Monitored

VTH or Management Center can monitor VTO image, and support max. 6-channel video stream monitoring.

Emergency Call

Press the key to call the Center in case of an emergency.

Auto Snapshot

Snapshot pictures automatically during unlock or talk, and store them in FTP.

Unlock

Realize unlock with card, fingerprint, password and remote unlock.

Alarm

Support tamper alarm, door sensor alarm and alarm of unlock with duress password. Meanwhile, report the alarm info to Management Center.

Record Search

Search call records, alarm records and unlock records.

2 Product Structure

2.1 Camera Module




Figure 2-1

No.	Name	Description
		Provide fill-in light for camera in case of insufficient light and
1	Fill-in light and user	display user info. Please use the user directory of the
'	directory	device; do not put other materials here, in order not to affect
		fill-in light effect.
2	Call key	Call the user or management center.
3	Microphone	Audio input.
4	Camera	Monitor the door area, with adjustable angle.
5	Speaker	Audio output.
6	Call indicator	Indicate the call status.
7	Talk indicator	Indicate the talk status.
8	Unlock indicator	Indicate the unlock status.

Table 2-1




Figure 2-2

No.	Name	Description
1	Camera angle adjusting column	Adjust camera angle.
2	Tamper switch	When VTO is detached from the wall forcibly, give out alarm sound and report alarm info to management centre.
3	User port	Provide power port, lock port, door sensor feedback port and exit button port to connect power supply, electric control lock, solenoid lock and exit button. Wiring method is shown in Figure 2-3 and Figure 2-4.
4	Cascade connection port	Connect other modules. NOTE In case of cascade connection of multiple modules, modules shall adopt cascade connection between each other.

Table 2-2




Figure 2-3




Figure 2-4

2.2 Button Module

Button module consists of one-button module, three-button module and five-button module; their functions are the same, although button quantity is different. Take "three-button module" for example.




Figure 2-5

No.	Name	Description
1	User directory	Display user info according to buttons.
2	Call key	Call the VTH.

Table 2-3




Figure 2-6

	No.	Name	Description
	1	Cascade input port	Connect other modules.
ſ	2	Cascade output port	

Table 2-4

2.3 Keyboard Module (with Braille)

NOTE

Rear panel of keyboard module is the same as rear panel of button module.




Figure 2-7

No.	Name	Description
1	Call management centre	Call management centre.
2	Numeric key	Input the password. For example, unlock password is 123456. Please input "#+ unlock password +#".
3	Call key	Call the VTH.

Table 2-5

2.4 Card Swiping Module

NOTE

Rear panel of card swiping module is the same as rear panel of button module.




Figure 2-8

No.	Name	Description
1	Card swiping area	It is valid to swipe the card here.
2	Proximity sensor	When a person is about 1m away from the device, the device will sense the person's approaching. Backlights of display screens of all modules and the keyboard will be turned on automatically. And they will turn off automatically after the person leaves.

Table 2-6

2.5 Fingerprint Module

NOTE

Rear panels of fingerprint module and button module have different port positions, but port functions are the same.




Figure 2-9

No.	Name	Description
1	Fingerprint module	The user inputs a fingerprint or unlocks with a fingerprint.

Table 2-7

2.6 Blank Module

NOTE

Rear panels of blank module and button module have different port positions, but port functions are the same.




Figure 2-10

No.	Name	Description
1	User directory	Display user info according to buttons.

Table 2-8

2.7 Networking Diagram

Networking diagram of the device is shown as follows:




Figure 2-11

3 Networking Diagram

2-wire Modular VTO consists of 9 modules at most. Camera module is indispensable, whereas max. 1 keyboard, card swiping, fingerprint module can be included.

3.1 One-to-one Scene




Figure 3-1

3.2 One-to-many Scene

Generally, unit VTO is installed at the gate of apartment building, whereas 2-wire Modular VTO is installed at the resident's gate. The operation process is as follows.

Step 1 The visitor calls any resident with unit VTO.

The resident's VTH rings. After unlocking, the visitor goes into the apartment building.

Step 2 Call the resident with 2-wire Modular VTO, and ask the resident to unlock the house.

NOTE
If keyboard module is connected, dial VTH room number to call.

Networking diagram is shown in Figure 3-2.




Figure 3-2

3.3 Group Call Scene

When the visitor presses call key on 2-wire Modular VTO, multiple VTHs ring at the same time; the resident can pick up, hang up or unlock on any VTH.

Networking diagram is shown in Figure 3-3.

M NOTE

- If keyboard module is connected, dial master VTH room number to call.
- VTH consists of master VTH and extension VTH. There is 1 master VTH at most and 5 extension VTHs at most.




Figure 3-3

Device Mounting

2-wire Modular VTO consists of single module mounting, double module mounting and 3-module mounting. Take 3-module mounting for example.



CAUTION

- When leaving factory by default, visiting cards and card cover have been included in the attachment.
- When power-on after mounting, please ensure that all modules have been connected; otherwise, they fail to work normally.
- Before installation of surface mounting box and flush mounting box, cables in the wall shall go through the bracket or flush mounting box.

4.1 Surface Mounting

- Step 1 Drill holes according to hole positions of surface mounting box, and put expansion pipe in place.
- Step 2 Fix surface mounting box onto the wall with ST3×18 screws.
- Step 3 Fix every module onto front panel with M3x6 screws.
- Step 4 Connect cables. Please refer to "2 Product Structure".
- Step 5 Fix the front panel onto surface mounting box with M4×40 screws.
- Step 6 Apply glue between surface mounting box and the wall.
- Step 7 Write room number or the user's name on the visiting card, and insert it into user directory.




Figure 4-1




Figure 4-2

4.2 Flush Mounting

Step 1 Dig a hole in the wall.

₩ NOTE

- Regarding single module mounting, hole dimension is 115mm×115mm×57mm.
- Regarding double module mounting, hole dimension is 237mm×125mm×50mm.
- Regarding 3-module mounting, hole dimension is 349mm×125mm×50mm.
- Step 2 Embed flush mounting box into the wall; ensure that box edge clings to the wall.
- Step 3 Fix every module onto front panel with M3x6 screws.
- Step 4 Connect cables. Please refer to "2 Product Structure".
- Step 5 Fix the front panel onto flush mounting box with M4x40 screws.
- Step 6 Apply glue among front panel, flush mounting box and the wall.
- Step 7 Write room number or the user's name on the visiting card, and insert it into user directory.




Figure 4-3




Figure 4-4

5 Device Debugging

5.1 Debugging Settings

5.1.1 VTO Settings

5.1.1.1 Initialization

For the first time, please initialize login password.

MOTE

Please ensure that default IP addresses of PC and VTO are in the same network segment. Default IP address of VTO is 192.168.1.110.

- Step 1 Connect power supply of VTO, and power on.
- Step 2 Enter default IP address of VTO at the address bar of PC browser.

 The system displays "Setting" interface, as shown in Figure 5-1.




Figure 5-1

Step 3 Enter "New Password" and "Confirm", and click "Next".

The system displays "Protect" interface, as shown in Figure 5-2.

NOTE

This password is used to login WEB interface. It shall be at least 8 characters, and shall include at least two types of number, letter and symbol.




Figure 5-2

Step 4 Select "Email" and enter your Email address.

This Email address is used to reset the password, so it is recommended that it should be set.

Step 5 Click "Next".

The system displays "OK" interface, as shown in Figure 5-3, and shows "Device succeeded!"




Figure 5-3

Step 6 Click "OK".

The system displays WEB login interface, as shown in Figure 5-4.



Figure 5-4

Step 7 Enter user name and password, and click "Login".

Log in the WEB interface of the device.

NOTE

- Default user name is admin.
- Password is the one set during initialization.

5.1.1.2 Modify Device Network

Modify IP address of VTO to the planned IP address.

Step 1 Select "System Config> Network Config> TCP/IP".

The system displays "TCP/IP" interface, as shown in Figure 5-5.




Figure 5-5

- Step 2 Enter the planned "IP Address", "Subnet Mask" and "Default Gateway", and click "OK".

 After modification is completed, VTO reboots automatically, while the following two cases occur at WEB interface.
 - If PC is in the planned network segment, WEB interface jumps to new IP login interface automatically.
 - If PC is not in the planned network segment, login will be failed. Please add PC to the planned network segment and login WEB interface again.

5.1.1.3 LAN Config

Configure VTO building no., unit no. and VTO no. info.

Step 1 Select "System Config> LAN Config".

The system displays "LAN Config" interface, as shown in Figure 5-6.




Figure 5-6

Step 2 Enter VTO "Building No.", "Building Unit No." and "VTO No.".

- NOTE
 - To call the management centre, please tick "Register to the MGT Centre", and set "MGT Centre IP Address" and "MGT Port No.". Enable or disable "No Answer Transfer MGT Centre".
 - To provide group call function, please tick "Group Call" and set "Max Extension Index", which is 5 at most.

Step 3 Click "OK".

5.1.1.4 Add VTH

Add VTH info. After VTH and VTO have completed debugging, VTH will be registered on VTO automatically and realize bonding.

- NOTE
- Add master VTH.
- After "Network" interface of extension VTH has added and enabled master VTH, VTO interface will obtain extension VTH info automatically.

Step 1 Select "System Config> Digital Indoor Station Manager".

The system displays "Digital Indoor Station Manager" interface, as shown in Figure 5-7.




Figure 5-7

Step 2 Click "Add".

The system displays "Add" interface, as shown in Figure 5-8.

Add		×
FamilyName		
FirstName		
Nick Name		
VTH Short No.		*
IP Address		
	OK Cancel	

Figure 5-8

Step 3 Enter VTH "Family Name", "First Name", "Nick Name", "VTH Short No." (VTH room no.) and "IP Address".

NOTE

It is OK if IP address is not filled in. After VTH is registered to VTO successfully, VTO will obtain IP address of VTH.

Step 4 Click "OK".

5.1.1.5 Set Modules

Camera module exists by default; all other modules shall be added in facade layout before use.



- At most 9 modules can be added.
- Regarding fingerprint module, card swiping module and keyboard module, only one module of each type can be added respectively. Other modules can be matched freely.

Step 1 Select "System Config>Local Config>Façade Layout".

The system displays "Façade Layout" interface, as shown in Figure 5-9.




Figure 5-9



The system displays available modules, as shown in Figure 5-10.



Figure 5-10

NOTE

If keyboard module, card swiping module and fingerprint module have been added already, they are not displayed here.

Step 3 Select modules according to actual layout of VTO.

NOTE

- Support continuous adding.
- Button module and camera module shall set corresponding relation of call key.
 For specific bonding operations, please refer to "Step 4~ Step 5". Other modules need not to set. Click "OK" to save.



The system displays "Room Config", as shown in Figure 5-11.

₩ NOTE

- The displayed room no. is the added VTH. To add VTH, please refer to "7.8.1 Add VTH".
- Click to modify the bonded buttons when necessary.




Figure 5-11

Step 5 Select room no. and click "OK".

The interface displays room no. info and corresponding button turns green, as shown in Figure 5-12.




Figure 5-12

Step 6 Click "Save" to save the settings.

After saving, reboot the device to take effect.

5.1.2 VTH Settings (Version 3.1)

5.1.2.1 Initialization

Set the password and bind your Email.

- Password: it is used to enter project setting interface.
- Email: it is used to retrieve your password when you forget it.

Step 1 Power on the device.

The system displays "Welcome" and enters "Device Initialization" interface, as shown in Figure 5-13.



Figure 5-13

Step 2 Enter "Password", "Confirm Pwd" and "Email".

Step 3 Click [OK].

The system displays "Info Init" interface, and click to turn off the interface.

5.1.2.2 Network Settings

Set VTH network info, which supports static IP and DHCP.

₩ NOTE

- IP addresses of VTH and VTO shall be in the same network segment. Otherwise, VTH will fail to obtain VTO info after configuration.
- To obtain IP with DHCP, please ensure the connected router has DHCP function and DHCP function has been enabled.
- Step 1 Select "System Config>Project Settings".

 The system pops up "Password" prompt box.
- Step 2 Enter the password set during initialization, and click [OK].
- Step 3 Click [Net Set].

The system displays "Net Set" interface, as shown in Figure 5-14.



Figure 5-14

Step 4 Set according to actual network access mode.

- Static IP
- 1. Select "Static IP".
- 2. Enter "Local IP", "Subnet Mask" and "Gateway".
- DHCP

Select "DHCP" to obtain IP address automatically.

Step 5 Click [OK] to save the settings.

5.1.2.3 Product Info Settings

Set VTH "Room No.", "Type" and "Master IP".

Step 1 Select "System Config>Project Settings".

The system pops up "Password" prompt box.

- Step 2 Enter the password set during initialization, and click [OK].
- Step 3 Click [Product Info].

The system displays "Product Info" interface, as shown in Figure 5-15.



Figure 5-15

Step 4 Set VTH info.

• Be used as a master VTH.

Enter "Room No." (such as 9901).

NOTE

"Room no." shall be the same with "VTH Short No.", which is set when adding VTH at WEB interface. Otherwise, it will fail to connect VTO.

- Be used as an extension VTH.
- 3. Press [Master] and switch to "Extension".
- 4. Enter "Room No." (such as 9901-1) and "Master IP" (IP address of master VTH).

NOTE

"User Name" and "Password" are the user name and password of master VTH. Default user name is admin, and the password is the one set during device initialization.

Step 5 Click "OK" to save the settings.

5.1.2.4 Network Terminal Setting

Add VTO and fence station info; at VTH interface, bind VTH with VTO and fence station.

Step 1 Select "System Config>Project Settings".

The system pops up "Password" prompt box.

- Step 2 Enter the password set during initialization, and click [OK].
- Step 3 Click [Network].

The system displays "Network" interface, as shown in Figure 5-16.



Figure 5-16

Step 4 Add VTO or fence station.

- Add main VTO.
- 1. In Figure 5-16, enter main VTO name, IP address, "User Name" and "Password".
- 2. Switch "Enable Status" to
 - NOTE
 - "User Name" and "Password" shall be consistent with WEB login user name and password of VTO. Otherwise, it will fail to connect.
 - "Enable Status" of main VTO is "ON" by default. After setting VTO info, please turn it off and then reboot, in order to put it into effect.
- Add fence station.
- Press to switch to sub VTO setting interface.
- 2. Select device type to be "fence station"; enter sub VTO name (fence station name), VTO middle no. (fence station middle no.), "User Name" and "Password".
- 3. Switch "Enable Status" to

Step 5 Click [OK] to save the settings.

5.1.3 VTH Settings (Version 4.0)

5.1.3.1 Initialization

Set the password and bind your Email.

- Password: it is used to enter project setting interface.
- Email: it is used to retrieve your password when you forget it.

Step 1 Power on the device.

The system displays "Welcome" and enters "Device Initialization" interface, as shown in Figure 5-17.



Figure 5-17

Step 2 Enter "Password", "Confirm Pwd" and "Email". Click [OK]. The system displays main interface.

5.1.3.2 Network Settings

Set VTH network info according to actual network access mode.

NOTE

IP addresses of VTH and VTO shall be in the same network segment. Otherwise, VTH will fail to obtain VTO info after configuration.

- Step 1 Press [Setting] for more than 6 seconds.
 - The system pops up "Password" prompt box.
- Step 2 Enter the password set during initialization, and click [OK].
- Step 3 Click [Network].

The system displays "Network" interface, as shown in Figure 5-18 or Figure 5-19.

₩ NOTE

Only devices with wireless function own wireless network access function.



Figure 5-18



Figure 5-19

Step 4 Set according to actual network access mode.

Wired IP

Enter "Local IP", "Subnet Mask" and "Gateway", press [OK]. Or press DHCP function and obtain IP info automatically.

NOTE

If the device has wireless function, please click "Wired IP" tab to set it.

- WLAN
- 1. Press OFF to enable WIFI function.

The system displays available WIFI list, as shown in Figure 5-20.



Figure 5-20

2. Connect WIFI.

The system has 2 access ways as follows.

- At "WLAN" interface, select WIFI, click "Wireless IP" tab to enter "Local IP", "Subnet Mask" and "Gateway", and press [OK].
- ♦ At "WLAN" interface, select WIFI, click "Wireless IP" tab, press ☐ OFF to enable DHCP function and obtain IP info automatically, as shown in Figure 5-21.
- NOTE

To obtain IP info with DHCP function, use a router with DHCP function.



Figure 5-21

5.1.3.3 VTH Config

Set VTH "Room No.", "Type" and "Master IP" info. Step 1 Press [Setting] for more than 6 seconds. The system pops up "Password" prompt box.

- Step 2 Enter the password set during initialization, and click [OK].
- Step 3 Click [VTH Config].

The system displays "VTH Config" interface, as shown in Figure 5-22.



Figure 5-22

Step 4 Set VTH info.

• Be used as a master VTH.

Enter "Room No." (such as 9901).

NOTE

"Room No." shall be the same with "VTH Short No.", which is set when adding VTH at WEB interface. Otherwise, it will fail to connect VTO.

- Be used as an extension VTH.
- 1. Press [Master] and switch to "Extension".
- 2. Enter "Room No." (such as 9901-1) and "Master IP" (IP address of master VTH).

NOTE

"Master Name" and "Master Pwd" are the user name and password of master VTH. Default user name is admin, and the password is the one set during device initialization.

Step 5 Press [OK] to save settings.

5.1.3.4 VTO Config

Add VTO and fence station info; at VTH interface, bind VTH with VTO and fence station.

- Step 1 Press [Setting] for more than 6 seconds.

 The system pops up "Password" prompt box.
- Step 2 Enter the password set during initialization, and click [OK].
- Step 3 Click [VTO Config].

The system displays "VTO Config" interface, as shown in Figure 5-23.



Figure 5-23

Step 4 Add VTO or fence station.

- Add main VTO.
- 1. In Figure 5-23, enter main VTO name, VTO IP, "User Name" and "Password".
- 2. Switch the "Enable Status" to be ON ...
 - NOTE
 - "User Name" and "Password" shall be consistent with WEB login user name and password of VTO. Otherwise, it will fail to connect.
 - "Enable Status" of main VTO is "ON" by default. After setting VTO info, please turn it off and then reboot, in order to put it into effect.
- Add fence station.
- Press to switch to sub VTO setting interface.
- 2. Select device type to be "Fence Station", enter sub VTO name (fence station name), VTO middle no. (fence station middle no.), "User Name" and "Password".
- 3. Switch the "Enable Status" to be ON

5.2 Debugging Verification

5.2.1 Verification with Version 3.1 VTH

5.2.1.1 VTO Calls VTH

Press call key at VTO or dial VTH room no. (9901) to call VTH. VTH pops up monitoring image and operating keys, as shown in Figure 5-24. It represents successful debugging.



Figure 5-24

5.2.1.2 VTH Monitors VTO

VTH is able to monitor VTO, fence station or IPC. Take "VTO" for example.

Select "Video Talk > Monitor > Door Station", as shown in Figure 5-25. Select the VTO to enter monitoring image, as shown in Figure 5-26.



Figure 5-25



Figure 5-26

5.2.2 Verification with Version 4.0 VTH

5.2.2.1 VTO Calls VTH

Press call key at VTO or dial VTH room no. (9901) to call VTH. VTH pops up monitoring image and operating keys, as shown in Figure 5-27. It represents successful debugging.

M NOTE

The following figure means that SD card has been inserted into VTH. If SD card is not inserted, recording and snapshot icons are gray.



Figure 5-27

5.2.2.2 VTH Monitors VTO

VTH is able to monitor VTO, fence station or IPC. Take "VTO" for example.

Select "Monitor > Door", as shown in Figure 5-28. Select the VTO to enter monitoring image, as shown in Figure 5-29.

NOTE

The following figure means that SD card has been inserted into VTH. If SD card is not inserted, recording and snapshot icons are gray.



Figure 5-28



Figure 5-29

6 Basic Function

6.1 Call Function

6.1.1 Call Management Centre

The system provides different calling ways depending on connected module.

- If 2-wire Modular VTO connects keyboard module, press on the keyboard module to call the management centre.
- If keyboard module is not connected, press call key of camera module to call the management centre.

Configure the following parameters before calling.

Step 1 Select "System Config >LAN Config".

The system displays "LAN Config" interface.

Step 2 Select "Register to the MGT Centre"; set "MGT Centre IP Address" and "MGT Port No.".

Register the VTO at management center.

- NOTE
 - To call from keyboard module, ensure that VTO has been registered at management centre.
 - To call by pressing the call key of camera module, it is necessary to enable "Call VTS or Not".
- Step 3 Set "Call VTS Time" and select "Call VTS or Not".

 Enable to call the management centre within the set time period.
- Step 4 Click "OK" to save the settings.




Figure 6-1

6.1.2 Single Call of VTH

Single call applies to the scene where one door corresponds to one VTH.

The system provides different calling ways depending on connected module.

Make a single call from camera module

Confirm the following configurations before call; press the call key of camera module to call VTH.

• Ensure to cancel the selection of "Call VTS or Not", as shown in Figure 6-2.




Figure 6-2

• Confirm whether call key is bound with VTH, as shown in Figure 6-3. Please refer to "7.7.2 Facade Layout" for details.





Figure 6-3

Make a group call from button module



Ensure that button module has been connected and added to façade layout. Otherwise, this call doesn't exist.

Before calling, confirm whether call key is bound with VTH, as shown in Figure 6-4. Press the call key on button module, to call the VTH. Please refer to "7.7.2 Facade Layout" for details.



Make a group call from keyboard module



Ensure that keyboard module has been connected and added to façade layout. Otherwise, this call doesn't exist.

On keyboard module, press VTH room no. and press to call the VTH.

6.1.3 Group Call

Group call applies to the scene where one VTO corresponds to multiple VTHs.



Please confirm that the following basic settings are correct, and confirm group call conditions for every connected module.

- Please ensure that single call between VTO and VTH works normally. If single call fails, please check the configuration by reference to "5.1 Debugging Settings".
- Room no. of extension VTH ends up with "-1, -2..." based on room no. of master VTH. For example, if master VTH is 9901, the extension VTH will be 9901-1, 9901-2...
- At WEB interface of VTO, select "System Config > LAN Config", set "Max Extension Index" and tick "Group Call" to enable group call function. There is one master VTH at most and five extension VTHs at most, as shown in Figure 6-5.




Figure 6-5

Make a group call from camera module

Confirm the following configurations before call; press the call key of camera module to call master VTH, and call other extension VTHs simultaneously.

- Ensure to cancel the selection of "Call VTS or Not", as shown in Figure 6-5.
- Confirm whether call key is bound with master VTH, as shown in Figure 6-6. Please refer to "7.7.2 Facade Layout" for details.




Figure 6-6

Make a group call from button module



Ensure that button module has been connected and added to façade layout. Otherwise, this call doesn't exist.

Before calling, confirm whether call key is bound with master VTH, as shown in Figure 6-7. Press the call key on button module, to call the master VTH, and call other extension VTHs simultaneously. Please refer to "7.7.2 Facade Layout" for details.




Figure 6-7

Make a group call from keyboard module



Ensure that keyboard module has been connected and added to façade layout. Otherwise, this call doesn't exist.

On keyboard module, dial master VTH room no. and press to call the master VTH, and call other extension VTHs simultaneously.

6.2 Unlock Function

6.2.1 Remote Unlock at VTH/VTS

When being called, during monitoring and calling status, the VTO will be unlocked remotely at VTS or VTH.

6.2.2 Open Door at WEB Interface

Step 1 Select "System Config >Video Set>Video Set".

The system displays "Video Set" interface.

Step 2 Click "Open Door", and VTO is unlocked, as shown in Figure 6-8.




Figure 6-8

6.2.3 Unlock with IC Card

Swipe the authorized IC card at card swiping module, so as to open the door.

- NOTE
- This function is valid only when card swiping module has been connected.
- Authorized IC card refers to a card that is issued and authorized to open the door. For card issuing operation, please refer to "6.3 Issue Card".

6.2.4 Unlock with Exit Button

If VTO is connected with exit button, press the exit button to open the door.

6.2.5 Unlock with Password

Support to unlock with personal password, unified password and duress password.

- Personal password is set at VTH. Please refer to matched VTH user's manual for details.
- Please refer to "7.7.3 Access Manager" for unified password and duress password setting.



Default unlock interval is 15s, and default unlock period is 2s. Please refer to "7.7.3 Access Manager" for details.

6.2.5.1 Unlock with Personal Password


In standby mode, press enter four-digit room no. (add 0 in front of room no. if it is less than

4 digits)+ personal password, and press again to unlock.

For example, 9901 user sets personal password to be 123456. Press #9901123456# to unlock.

6.2.5.2 Unlock with Unified Password

In standby mode, press, enter unified password (default password is 123456), and press



For example, XX user presses #123456# to unlock.

6.2.5.3 Unlock with Duress Password

In case of duress, press , enter duress password (default password is 654321), and press



again to unlock.

For example, XX user presses #654321# to unlock. At the time, the system sends alarm info to management centre.

6.3 Issue Card

Authorize IC card at VTO WEB interface, so the user can open door with authorized card. Support at most 10,000 cards.



This function is valid only when card swiping module has been connected and added to façade layout.

Step 1 Select "System Config > Local Config > A&C Manager".

The system displays "A&C Manager" interface, as shown in Figure 6-9.




Figure 6-9

Step 2 Click "Issue Card".

The system displays 30s countdown, as shown in Figure 6-10.



Figure 6-10

Step 3 Within 30s countdown, swipe an unauthorized card at VTO.

The system pops up "Card Info" interface, as shown in Figure 6-11.

Card Info		×
Room No.		
Card Number		
	OK Cancel	
	XXIII	

Figure 6-11

Step 4 Enter "Room No." and "Card No.". Click "OK".

NOTE

Cards can be swiped continuously, within a period of 30s.

Step 5 Click "OK" to finish issuing card.

NOTE

- Click "OK" within the countdown, so the cards will be valid. Otherwise, all card info will be invalid.
- Click "Cancel" when issuing cards, in order to stop issuing.

6.4 Monitoring Function

Both VTS and VTH can monitor the VTO.

VTO supports multi-channel stream monitoring. Available channels vary under different video formats. Support max. 4 channels with 720P, and support max. 6 channels with WVGA.

Video format is set as follows:

Step 1 At VTO WEB interface, select "System Config >Video Set>Video Set". The system displays "Video Set" interface.

Step 2 Select "Video Format".




Figure 6-12

6.5 Tamper Switch

Camera module is equipped with a tamper switch against the wall. In case that the device is disassembled from the wall, tamper switch will leave the wall too. The device will emit tamper alarm sound and report alarm info to management centre.

6.6 Restore Backup

If VTH info is modified by mis-operation during use, two restoration ways are available to restore them.



VTO saves VTH info of the system automatically every half an hour. If VTH info is modified by mis-operation, please restore them timely. Otherwise, the system will automatically save mis-operation info after half an hour.

Restore from backup data in device memory

Step 1 Select "System Config > Local Config > Config Manager".

The system displays "Config Manager" interface, as shown in Figure 6-13.



Figure 6-13

Step 2 Select "VTH Info" and click "Restore Backup".

Backup VTH info in the device will be restored to VTO.

Restore from local backup data

Step 1 Select "System Config >Indoor Manager".

The system displays "Digital Indoor Station Manager" interface, as shown in Figure 6-14.



Figure 6-14

- Step 2 Click "Import Config". The system displays "Open" interface.
- Step 3 Select config files (.log) and click "Open".

 The system displays "Success" to complete importing config.

WEB Config

7.1 Initialization



- For the first login or login after restoring factory defaults, please initialize WEB interface.
- Please ensure that default IP addresses of PC and VTO are in the same network segment.
 Otherwise, it fails to enter initialization interface.
- Step 1 Enter default IP address of VTO at the address bar of PC browser, and press [Enter] key. The system displays "Setting" interface, as shown in Figure 7-1.




Figure 7-1

Step 2 Enter "New Password" and "Confirm", and click "Next".

The system displays "Protect" interface, as shown in Figure 7-2.

This password is used to login WEB interface. It shall be at least 8 characters, and shall include at least two types of number, letter and symbol.




Figure 7-2

- Step 3 Select "Email" and enter your Email address.

 This Email address is used to reset the password, so it is recommended that it should be set.
- Step 4 Click "Next". The system displays "OK" interface, as shown in Figure 7-3 and shows "Device succeeded!"




Figure 7-3

Step 5 Click "OK".

The system displays WEB login interface.

7.2 Reset the Password

If you forget login password of admin user, please reset the login password by scanning QR code.

Step 1 Log in WEB interface of the device through browser,.

The system displays login interface, as shown in Figure 7-4.



Figure 7-4

Step 2 Click "Forgot Password".

The system displays "Reset the password" dialog box, as shown in Figure 7-5.



Figure 7-5

Step 3 Scan the QR code according to interface prompts and obtain security code.



- Two security codes can be obtained by scanning the same QR code. To obtain security code again, please refresh QR code.
- After receiving security code in your Email, please reset the password with the security code within 24 hours. Otherwise, the security code will become invalid.
- If wrong security code is entered for 5 times continuously, this account will be locked for 5 min.
- Step 4 Please enter the received security code in the dialog box.
- Step 5 Click "Next".

The system displays new password setting interface, as shown in Figure 7-6.



Figure 7-6

Step 6 Set "New Password" and "Confirm".

Password can be 8 to 32 non-null characters; it consists of letters, numbers and symbols (except "", "", ";", ":" and "&"). The password shall consist of 2 types or over 2 types. Please set a high-security password according to password strength prompt.

Step 7 Click "OK" to complete resetting.

7.3 System Login



CAUTION

Please ensure that IP addresses of PC and VTO are in the same network segment; otherwise, it fails to enter WEB login interface.

Step 1 Enter IP address of VTO at the address bar of PC browser, and press [Enter] key. The system displays WEB login interface, as shown in Figure 7-7.



Figure 7-7

Step 2 Enter username and password, and click "Login".

Log in the WEB interface of the device.

- NOTE
- Default username is admin.
- Password is the one set during initialization.

7.4 User Manager

Add, delete and modify WEB user info.

Select "System Config > User Manager". The system displays "User Manager" interface, as shown in Figure 7-8.



Figure 7-8

7.4.1 Add User

The added user enjoys all operating authorities except adding user and admin user management.

Step 1 Click "Add User".

The system displays "Add User" interface, as shown in Figure 7-9.

Add User		×
Username		
Password		
	Weak Middle Strong	
Confirm		
Remark	95	
Use a password that has 8 to numbers and symbols (plea	o 32 characters, it can be a combination of letters, see do not use special symbols like '、"、;、:、&) OK Cancel	

Figure 7-9

Step 2 Enter "Username", "Password", "Confirm" and remark.



Password is required to be at least 8 characters, and shall include at least two types of number, letter and symbol.

Step 3 Click "OK" to complete adding.

7.4.2 Modify User

7.4.2.1 Modify Admin User

Admin user can modify his/her own user password and Email address. Email address is used to reset the password and receive info.

Step 1 Click in the line of admin user info.

The system displays "Modify User" interface, as shown in Figure 7-10.



Figure 7-10

Step 2 Modify user info.

1. Tick "Change Password".

The system displays password change interface, as shown in Figure 7-11.

Modify User		×
✓ Change Password		
Old Password		
New Password		
	Weak Middle Strong	
Confirm	- 100	
Email Address	9***@qq.com	Modify email
Remark	admin 's account	
	o 32 characters, it can be a combinese do not use special symbols like	

Figure 7-11

- 2. Enter "Old Password", "New Password" and "Confirm".
- 3. Tick "Modify Email" to enter Email address.
- 4. Click "OK".

7.4.2.2 Modify Ordinary User

Ordinary user refers to other uses except admin user. Admin user can modify remark and password of all other users, while ordinary user can modify his/her own password only. Take admin user modifying ordinary user for example.

Step 1 Click in the line of ordinary user info.

The system displays "Modify User" interface, as shown in Figure 7-12.




Figure 7-12

Step 2 Modify user info, as shown in Figure 7-13.

Tick "Change Password".

The system displays password change interface, as shown in Figure 7-13.



Figure 7-13

- 2. Enter "Old Password", "New Password" and "Confirm".
- 3. Update remark.
- 4. Click "OK".

7.4.3 Delete User

Click in the line of user info that requires deletion, in order to delete this user.

7.5 Network Parameter Config

Set IP address, FTP server, application port, DDNS, HTTPS, UPnP and IP authority.

7.5.1 Network Config

Set IP address of VTO.

Step 1 Select "System Config > Network Config > TCP/IP".

The system displays "TCP/IP" interface, as shown in Figure 7-14.



Figure 7-14

- Step 2 Enter the planned "IP Address", "Subnet Mask" and "Default Gateway".
- Step 3 Turn on SSH according to needs.

 After SSH is on, Telnet and other debugging terminals can connect VTO, operate and debug it.
- Step 4 Click "OK" to save the settings.

7.5.2 FTP Server

Set FTP server, so recordings and snapshots will be saved in FTP server.

Step 1 Select "System Config > Network Config > FTP".

The system displays ""FTP" interface, as shown in Figure 7-15.




Figure 7-15

Step 2 Set the parameters and refer to Table 7-1 for details.

Parameter	Description
IP Address	IP address of the host to install FTP server.
Port No.	It is 21 by default.
Username	Username and password to visit FTP server.
Password	

Table 7-1

Step 3 Click "OK" to save the settings.

7.5.3 Port

Set the port to visit WEB interface of VTO.

Step 1 Select "System Config > Network Config > Port".

The system displays "Port" interface, as shown in Figure 7-16.




Figure 7-16

Step 2 Set port value of this device and refer to Table 7-2 for details.

Parameter	Description	
TCP Port	Communication port of TCP protocol, to be set according to the user's actual	
	needs. It is 37777 by default.	
UDP Port	User datagram protocol port, to be set according to the user's actual needs.	
	It is 37778 by default.	
Web Port	Port to visit WEB interface of VTO, to be set according to the user's actual	
	needs. It is 80 by default.	
	 Default RTSP port no. is 554, which can be left unfilled if it is default. The user plays real-time monitoring with Apple browser QuickTime or VLC. Blackberry mobile phones also support this function. URL format of real-time monitoring stream: to request RTSP streaming service of real-time monitoring, please designate the requested channel no. and stream type in URL. In case of need for certification info, please provide username and password. To visit with Blackberry mobile phones, set stream coding mode to be H.264B and resolution to be CIF. Turn off audio. URL format is described as follows: rtsp://username:password@ip:port/cam/realmonitor?channel=1&subtype=0 	
	Username: username, such as admin.	
	Password: password, such as admin.	
DTCD Dow	IP: device IP, such as 10.7.8.122.	
RTSP Port	Port: port no., which is 554 by default. It can be left unfilled if it is default.	
	Channel: channel no. starting with 1. If channel is 2, channel=2.	
	Subtype: stream type. Main stream is 0 (subtype=0), while extra stream	
	is 1(subtype=1).	
	For example, to request extra stream of channel 2 of a device, URL is as	
	follows:	
	rtsp://admin:admin@10.12.4.84:554/cam/realmonitor?channel=2&subtype= 1	
	If certification is unneeded, it is unnecessary to designated username and	
	password. Use the following format:	
	rtsp://ip:port/cam/realmonitor?channel=1&subtype=0	

Table 7-2

Step 3 Click "OK" to save the settings.

In case that the port is modified, enter "http://VTO IP: WEB port no." in the browser, to

7.5.4 DDNS Server

In case of frequent changes in IP address of the device, DDNS (Dynamic Domain Name Server) dynamically updates the relation between domain name and IP address on DNS server, and ensures that users are able to visit the device through domain name.



CAUTION

- Before configuration, please check if the device supports DDNS server; login corresponding DDNS website to register username, password and domain name info.
- After the user registers successfully on DDNS website and logins, view the registered user's all connected devices.
- Step 1 Select "System Config > Network Config > DDNS".

The system displays "DDNS" interface, as shown in Figure 7-17.




Figure 7-17

Step 2 Tick "Enable" to enable DDNS server function.

Set parameters and refer to Table 7-3 for details.

Parameter	Description
Server Type	Server type refers to name of DDNS server provider. Relation between
	server type and server name is as follows.
Server Name	Dyndns DDNS address is: members.dyndns.org.
	NO-IP DDNS address is: dynupdate.no-ip.com.
Server Port	Port no. of DDNS server.
Realm	Domain name registered by the user at the website of DDNS server
	provider.
User	User name and password obtained from DDNS server provider. The user
Password	needs to register (including user name and password) at the website of
	DDNS server provider.
DDNS Live Time	The time interval to raise update request after designated DDNS update is
	enabled. The unit is second.

Table 7-3

Step 3 Click "OK" to save the settings.

Enter domain name in the browser and press [Enter] key. Configuration has succeeded

if WEB login interface of the device is displayed, and configuration has failed if WEB login interface is not displayed.

7.5.5 P2P

P2P is a private network traversal technology. After enabling P2P function, open mobile client software, enter the serial number directly or scan the QR code to obtain serial number, and thus manage multiple controllers. During easy and convenient use, it is unnecessary to apply for dynamic domain name, carry out port mapping or deploy relay server.



CAUTION

To use this function, the device shall be connected with Internet, in order to use it normally. Step 1 Select "System Config > Network Config > P2P".

The system displays "P2P" interface, as shown in Figure 7-18.



Figure 7-18

- Step 2 Tick "Enable" to enable P2P function.
- Step 3 Select "P2P Server".
- Step 4 Click "OK" to complete setting.

After the setting has been completed, "Status" becomes "Online", representing successful P2P registration.

After successful P2P registration, enter the serial number directly to add VTO, in order to visit and manage VTO.

7.5.6 HTTPS Setting

At HTTPS setting interface, create server certificate or download root certificate and set port number, so PC is able to login through HTTPS. In this way, ensure communication data security; guarantee user info and device security with reliable stable technology.

Step 1 Select "System Config > Network Config > HTTPS Setting".

The system displays "HTTPS Setting" interface, as shown in Figure 7-19.




Figure 7-19

Step 2 Enter "Port", tick "HTTPS Enable" and thus enable the HTTPS function.

Step 3 Click "OK" to save the settings.

NOTE

- If you use this function for the first time or change device IP, execute "Create" again.
- If you use HTTPS for the first time after changing computer, execute "Download Certificate" again.

7.5.7 UPnP

Via UPnP protocol, create mapping relationship between private network and WAN. WAN user can visit device in LAN via outer IP address.



Please confirm the following operation before use.

- UPnP function is used only when VTO is connected with router.
- Enable UPnP function of the router, set IP address of router WAN port (WAN IP), and connect WAN.
- Connect the device with router LAN port, and connect private network.

Select "System Config > UPnP Config", and the system displays "UPnP" interface, as shown in Figure 7-20.




Figure 7-20

7.5.7.1 Enable Mapping

There are some mapping relations when leaving factory, which can be used after being enabled.

Step 1 Tick "UPnP Enable" to enable UPnP function.

- Step 2 Select servers to enable mapping relation.
- Step 3 Click "OK" to save the settings.

Enter "http://WAN IP: External Port No." in the browser, to visit private network device at corresponding port in the router.

7.5.7.2 Add Server

Add new server mapping relations.

Step 1 Click "Add".

The system displays "Add" interface, as shown in Figure 7-21.




Figure 7-21

Step 2 Set parameters and refer to Table 7-4 for details.

Parameter	Description	
Enable/ Disable	 Tick "Enable" to enable the mapping relation. Tick "Disable", meaning that mapping relation is not enabled. Choose to enable it in the external list. 	
Server Name	Name of network server.	
Protocol	Protocol type.	
Inport	Port that this device needs to map. NOTE When you set router mapping outer port, try to use port within 1024~5000, avoid using well-known port 1~255 and system port 256~1023, in order to prevent conflicts. When there are multiple devices in the same LAN,	
Outport	Port that is mapping to one outer port. For port mapping in progress, please make sure mapping port is not occupied or limited. TCP/UDP inports and outports must be identical, and they cannot be modified.	

Table 7-4

Step 3 Click "OK" to save the settings.

7.5.7.3 Modify Server

Modify server mapping relation in the list.

Step 1 Click <a>^.

The system displays "Add" interface, as shown in Figure 7-22.




Figure 7-22

Step 2 Set parameters and refer to Table 7-4 for details.

Step 3 Click "OK" to save the settings.

7.5.7.4 Delete Server

Delete server mapping relation in the list.

Click to delete mapping relation.

7.5.8 IP Purview

In order to strengthen device network security and protect device data, set access purview of IP host (IP host refers to personal computer or server with IP).

- White list allows designated IP host to visit the device.
- Black list prohibits designated IP host from visiting the device.

Step 1 Select "System Config > IP Purview".

The system displays "IP Purview" interface, as shown in Figure 7-23.



Figure 7-23

Step 2 Tick "Enable".

The system displays white/black list checkbox, as shown in Figure 7-24.




Figure 7-24

- 1. Add "White" or "Black".
- 2. Click "Add".

The system displays "Add" interface, as shown in Figure 7-25.




Figure 7-25

3. Set IP address and refer to Table 7-5 for details.

The system supports to set maximum 64 IP addresses.

Туре	Description
IP Address	Add host IP address to be added; adopt IPv4 format, such
	as 192.168.1.120.
IP Network Segment	Enter the start address and end address of network
	segment to be added.

Table 7-5

4. Click "OK".

Return to IP purview interface.

Step 3 Click "OK" to save the settings.

IP host in the white list can login WEB interface of the device successfully. The system displays "Login Failed" if IP host in the black list logins the WEB interface.

7.6 LAN Config

Set VTO building no., unit no., no., management centre and group call function.

Step 1 Select "System Config > LAN Config".

The system displays "LAN Config" interface, as shown in Figure 7-26.

System Config	LAN Config	
> Local Config		
> LAN Config	Building No.	01
> Indoor Manager	Building Unit No.	1
> Network Config	VTO No.	6901
> Video Set	Max Extension Index	5 Group Call
> User Manager		
> IP Purview	MGT Centre IP Address	10.22.5.254
IPC InformationUPnP Config	MGT Port No.	12801
Info Search	Call VTS Time	00 ✓ : 00 ✓ To 23 ✓ : 59 ✓ □ Call VTS Or Not
Status Statistics	NoAnswer Transfer MGT	
Logout	Centre	Eliable
00.		
1 3 h		Warning:The device needs reboot after modifing the config above.
55		If extensionCount changed,need reboot VTH and init VTH information again!
00		Default Refresh OK
-3\ ⁰		

Figure 7-26

Step 2 $\,$ Set parameters and refer to Table 7-6 for details.

Parameter	Description	
Building No.	Set building no. of VTO.	
Building Unit No.	Set unit no. of VTO.	
VTO No.	Set no. of VTO.	
Max. Extension	Tick "Group Call" to enable VTO group call function; press the call key on	
Index	the VTO, to call master VTH and extension VTH simultaneously. Max.	
	quantity of group call extension VTH shall not exceed "Max. Extension Index".	
	If call key of the camera has been bound with master VTH, press the call key to make a call.	
	If VTO has been connected with button module and bound with master VTH, press the call key to make a call.	
Group Call	 If VTO has been connected with keyboard module, dial room no. of 	
Group Can	master VTH to make a call.	
	NOTE	
	 After group call function is enabled or disabled, the device reboots 	
	automatically, so the configuration takes effect.	
	To realize group call, VTH and VTO shall be set. Please refer to	
	"6.1.3 Group Call".	
MGT Centre IP	Set "MGT Centre IP Address" and "MGT Port No."; tick "Register to the	
Address	MGT Centre". VTO is registered to management centre, so management	
MGT Port No.	centre can manage the VTO and VTH, and call VTH.	
Register to the	NOTE	
MGT Centre	Please obtain management centre info in advance.	

Parameter	Description
Call VTS Time	\wedge
	Z!\ CAUTION
Call VTS or Not	Ensure that VTO has been registered at management centre.
Call V 13 Of NOt	Set "Call VTS Time" and tick "Call VTS or Not". Press the call key on the
	VTO within the set time period, to call the management centre only.
	Tick "Enable" to enable transferring to management centre in case of no
	answer.
No Answer	In the following cases when VTO calls VTH, the system will transfer the
Transfer MGT	call to management centre automatically.
Centre	SD card has not been inserted into VTH.
	SD card has been inserted into VTH, but VTO message time is set
	to be 0 on the VTH.

Table 7-6

Step 3 Click "OK" to save the settings.

7.7 Local Parameter Config

7.7.1 Local Config

Set info about the device, such as device type and reboot date.

Step 1 Select "System Config > Local Config > Local Config".

The system displays "Local Config" interface, as shown in Figure 7-27.



Figure 7-27

Step 2 Set parameters and refer to Table 7-7 for details.

Parameter	Description
Sensor	If it is dark during video intercom, turn on the fill-in light automatically.
	The larger the value is, the higher sensitivity becomes.
Device Type	It is villa station by default.
Reboot Date	Set auto reboot time of VTO. It is 2 a.m. on Tuesday by default.
Version Info	Display software version number.
Dial Rule	Set the user's dial rule, including "Non-serial" and "Serial".

Table 7-7

Step 3 Click "OK" to save the settings.

7.7.2 Facade Layout

Camera module exists by default; all other modules shall be added in facade layout before use.



- At most 9 modules can be added.
- Regarding fingerprint module, card swiping module and keyboard module, only one module of each type can be added respectively. Other modules can be matched freely.

7.7.2.1 Add Modules

Step 1 Select "System Config>Local Config>Façade Layout".

The system displays "Façade Layout" interface, as shown in Figure 7-28.




Figure 7-28



The system displays available modules, as shown in Figure 7-29.

NOTE

If keyboard module, card swiping module and fingerprint module have been added already, they are not displayed here.



Figure 7-29

Step 3 Select modules according to actual layout of VTO.



Actual connection position of the device on WEB interface is from top to bottom and from left to right.

Support to add them continuously and save them together.

Step 4 Click "OK" to save the settings.

After saving, please reboot the browser to put it into effect.

7.7.2.2 Set Modules

After adding, button module and camera module shall set corresponding relation of call key. Step 1 Select "System Config>Local Config>Façade Layout".

The system displays "Façade Layout" interface, as shown in Figure 7-30.



Figure 7-30



The system displays "Room Config", as shown in Figure 7-31.

- NOTE
- The displayed room no. is the added VTH. To add VTH, please refer to "7.8.1 Add VTH".
- Click to modify the bonded buttons when necessary.




Figure 7-31

Step 3 Select room no. and click "OK".

The interface displays room no. info and corresponding button turns green, as shown in Figure 7-32.



Figure 7-32

Step 4 Click "Save" to save the settings.

After saving, reboot the device to take effect.

7.7.3 Access Manager

Set unlock responding interval, unlock period, door sensor check time, unlock password, menace password, auto snapshot and issue card..

Step 1 Select "System Config > Local Config > A&C Manager".

The system displays "A&C Manager" interface, as shown in Figure 7-33.

System Config	Local Config A	&C Manager Sound Control Talk Manager System Time Config Manager
> Local Config	Unlock Despending Interior	45
> LAN Config	Unlock Responding Interva	15
> Indoor Manager	Unlock Period	2
> Allocator Manager	Door Sensor Check Time	120 Check Door Sensor Signal Before Lock
> Network Config	Issue Card Password	
> Video Set	Project Password	
> User Manager		
> IP Purview	Lift Control Protoco	Local Protocol Lift Control Enable
> IPC Information	Password Unlock Type	Uniform Password
> VTO Info	New Unlock Password	
> IP Allocate Auto	New Unlock Password	
> Publish Information	Confirm	
> UPnP Config	New Menace Password	
► Info Search		
Status Statistics	New Menace Password	
Logout	Confirm	
100 m	Auto Snapsho	○ Enable • Disable
	Upload Unlock Record	○ Enable ● Disable
		Issue Card
		Default Refresh OK

Figure 7-33
Step 2 Set parameters and refer to Table 7-8 for details.

Parameter	Description	
Unlock Responding	After unlock, the interval that the device response	onds to the next
Interval	unlock. The unit is "second".	
Unlock Period	After unlock, the period that it remains unloc "second".	ked. The unit is
Check Door Sensor Signal Before Lock	Tick "Check Door Sensor Signal Before Lock function. If door sensor signal exists, it will not be	
Door Sensor Check Time	after opening time exceeds the door sensor checksensor alarm and report the alarm info to make automatically.	
Password Unlock Type	Support the following two ways:	
New Unlock Password	Personal password: it can be set at VTH.	
New Unlock Password Confirm	Unified password: after setting, every user of the unit can unlock with this password.	NOTE
New Menace Password	Tick "Menace Password Enable" to enable this function.	This parameter is displayed
New Menace Password Confirm	In case of menace, input the menace password to unlock; the device uploads the alarm info to management center automatically.	after keyboard module is connected and
Auto Snapshot	Tick "Enable". 2 pictures will be snapshot automatically when the door is opened, and uploaded to FTP.	added to façade layout.
Upload Unlock Record	Reserved function.	

Parameter	Description	
Issue Card	 Click "Issue Card". Swipe the unauthorized card at VTO. Pop up "Card Info" interface. Enter "Room No." and "Card No.", and click "OK". NOTE Cards can be swiped continuously, within a period of 30s. Click "OK" to finish issuing card. NOTE Click "OK" within the countdown, so the cards will be valid. Otherwise, all card info will be invalid. Click "Cancel" when issuing cards, in order to stop issuing. 	NOTE This parameter is displayed after card swiping module is connected and added to façade layout.

Table 7-8

Step 3 Click "OK" to save the settings.

7.7.4 Sound Control

Enable and disable unlock sound, ringtone, alarm sound and speech sound.

Step 1 Select "System Config > Local Config > Sound Control".

The system displays "Sound Control" interface, as shown in Figure 7-34.



Figure 7-34

- Step 2 Enable or disable corresponding sound.
- Step 3 Click "OK" to save the settings.

7.7.5 Talk Manager

Set the auto snapshot, message and record upload functions during talk.



Auto snapshot, message and record are uploaded to FTP. Please confirm that FTP server has been configured.

Step 1 Select "System Config > Local Config > Talk Manager".

The system displays "Talk Manager" interface, as shown in Figure 7-35.



Figure 7-35

Step 2 Set parameters and refer to Table 7-9 for details.

Parameter	Description
	Tick "Enable". 2 pictures will be snapshot automatically during calling,
Auto Snapshot	and 1 picture will be snapshot automatically when pickup, and then
	uploaded to FTP.
	CAUTION If VTH doesn't have SD card or SD card isn't inserted, enable this
	function and set FTP server to realize this function.
Leave Message	If VTH has SD card, the messages and records will be saved on the
Upload	VTH automatically. This function is invalid.
	Tick "Enable" to enable the function. VTH info interface has "Visitors'
	Message" tab. When VTO calls VTH and gets no response, the system
	prompts that "No one answers. Please press 1 to leave a message".
	Press [1] to leave a picture/message. The system will upload the
	contents to FTP and messages are available at "Visitors' Message" tab.
Upload Talk	Reserved function.
Record	Neserveu iuriciiori.

Table 7-9

Step 3 Click "OK" to save the settings.

7.7.6 System Time

Set system date format, time format, system time and NTP server.

Step 1 Select "System Config > Local Config > System Time".

The system displays "System Time" interface, as shown in Figure 7-36.




Figure 7-36

Step 2 Set parameters and refer to Table 7-10 for details.

Parameter	Description
Date Format	Set date display format, including Year-Month-Day, Month-Day-Year
	and Day-Month-Year.
Time Format	Set time display format, including 12-hour standard and 24-hour
Time Format	standard.
	Set present system date and time of VTO.
System Time	A CAUTION
System rans	System time shall not be changed arbitrarily; otherwise, it may fail to
	inquire records and snapshots or release info. Before changing system
	time, please stop recording or disable auto snapshot.
Sync PC	Click "Sync PC", so system time and local PC time are consistent.
DST Enable	Some countries or regions follow daylight-saving time (DST). Choose
DST Type	to enable DST or not according to actual needs:
Start Time	Tick "DST Enable" to enable DST function.
End Time	2. Select "DST Type", including "Date" and "Week".
End fille	3. Set the start time and end time of DST.
NTP Enable	Tick "NTP Enable" to enable this function.
NTP Server	Enter domain name or IP address of NTP server.
Zone	Select time zone of the device.
Port No.	Set port no. of NTP server.
Undata Pariod	The time interval of updating time between device and NTP server.
Update Period	Maximum update period is 30 minutes.

Table 7-10

Step 3 Click "OK" to save the settings.

7.7.7 Config Manager

Realize backup or restore backup, VTH info, local config, networked config and video config; restore all default configurations.

Select "System Config > Local Config > Config Manager". The system displays "Config Manager" interface, as shown in Figure 7-37.



Figure 7-37

- Backup
 - Select "VTH Info", and click "Backup", so VTH info will make a backup in VTO.
- Restore Backup
 - Click "Restore Backup", so card info and VTH info is restored to backup info.
- Export Config
 - Click "Export Config" to export config info and save it at local device, so as to restore config or import into other devices.

- Import Config
 Click "Import Config" to import local config files to the device, so as to restore data or synchronize data.
- Default All
 Click "Default All". After confirmation, the device will reboot, and restore all info to default status, except IP address.

7.8 Indoor Manager

Manage VTH info and card info in the system. Select "System Config > Indoor Manager", and the system displays "Digital Indoor Station Manager" interface, as shown in Figure 7-38.



Figure 7-38

7.8.1 Add VTH

- NOTE
- Add master VTH.
- After "Network" interface of extension VTH has added and enabled master VTH, VTO interface will obtain extension VTH info automatically.

Step 1 Click "Add".

The system displays "Add" interface, as shown in Figure 7-39.




Figure 7-39

Step 2 Set parameters and refer to Table 7-11 for details.

Parameter	Description
Family Name	
First Name	Set VTH user name and nick name, in order to identify VTH.
Nick Name	

Parameter	Description
	Set VTH room no
VTH Short No.	NOTE NOTE
	VTH short no. is the same as room no. configured at VTH.
IP Address	VTH IP address.

Table 7-11

Step 3 Click "OK" to save the settings.

7.8.2 Modify VTH

NOTE

Only family name, first name and nick name of VTH can be modified.



The system displays "Modify" interface, as shown in Figure 7-40.




Figure 7-40

Step 2 Modify VTH "Family Name", "First Name" and "Nick Name".

Step 3 Click "OK" to save the settings.

7.8.3 Delete VTH

Click on to delete VTH info one by one.

7.8.4 QR Code

Every VTH provides a QR code. Connect mobile phone client with P2P function, so all info is pushed to the client, in order to receive and view them conveniently.

Click to enter username and password, click "OK", and display QR code and serial number of this VTH, as shown in Figure 7-14.



Figure 7-41

- NOTE
- Scan this QR code with mobile phone client. Before adding the device, ensure that VTO P2P function has been enabled. Please refer to "7.5.5 P2P" for details.
- Username and password are the ones to login WEB interface of VTO.

7.8.5 Config Manager

Import or export device info, password info, card no. info and login info of the device.

7.8.5.1 Export Config

Export and save config in the local device. When other devices need to configure the same parameters, the config file can be imported.

Step 1 Click "Export Config".

The system displays "Export" interface, as shown in Figure 7-42.




Figure 7-42

- Step 2 Select "Export Type" and click "OK".
- Step 3 Select a location to save it.
- Step 4 Click "Save".

The system prompts "Operation Succeeded", representing successful export.

7.8.5.2 Import Config

Import local config file into the device, so as to realize configuration.

Step 1 Click "Import Config".

The system displays "Open" interface.

Step 2 Select config file (.log) to be imported and click "Open".

The system prompts "Operation Succeeded", representing successful import.

7.8.6 Card Manager

Issue card, report loss and cancel, modify card ID and delete card.

7.8.6.1 Report Loss

If one card is lost, report loss of the card. The card doesn't have authority to unlock the door, until the report is cancelled.

Step 1 Click

The system displays "Card Info" interface, as shown in Figure 7-43.



Figure 7-43

NOTE

2-wire Modular VTO doesn't support main card function.

Step 2 Click to report loss, and the icon is switched to



Click to cancel the report and restore unlock function.

Step 3 Click K to close config interface.

7.8.6.2 Modify

Modify username of the card.

Step 1 Click

The system displays "Card Info" interface, as shown in Figure 7-43.

Step 2 Click 2.

The system displays "Modify" interface, as shown in Figure 7-44.




Figure 7-44

Step 3 Modify username of the card.

Step 4 Click "OK".

Step 5 Click X to close config interface.

7.8.6.3 Delete

After deletion, the card doesn't own unlock authority.

Step 1 Click .

The system displays "Card Info" interface, as shown in Figure 7-43.

Step 2 Click of to delete card info.

Step 3 Click X to close config interface.

7.9 Video Set

Set video picture and audio volume of VTO with camera.

7.9.1 Video Set

Step 1 Select "System Config > Video Set > Video Set".

The system displays "Video Set" interface, as shown in Figure 7-45. Click "Open Door", and VTO is unlocked.




Figure 7-45

Step 2 Set parameters and refer to Table 7-12 for details.

Parameter		Description	
	Video Format	Adjust resolution of video, including 720P, WVGA and D1.	
Main Format	Frame Rate	Adjust transmission speed, including 3, 25 and 30 frames.	
	Bitrate	Select according to actual access network, including 256Kbps,	

Parameter		Description		
		512Kbps, 1Mbps, 2Mbps and 3Mbps.		
	Video Format	Adjust resolution of video, including WVGA, D1, QVGA and CIF.		
Extra	Frame Rate	Adjust transmission speed, including 3, 25 and 30 frames.		
Format	Traine rate	Select according to actual access network, including 256Kbp		
Tomat	Bitrate	512Kbps, 1Mbps, 2Mbps and 3Mbps.		
		Adjust overall brightness in a linear way. The larger the value is,		
Brightness		the brighter the image becomes; and vice versa. When this value		
		is large, the image dims easily.		
		Adjust image contrast. The larger the value is, the more		
		contrasted the image becomes; and vice versa. When this value		
Contrast		is large, dark part of the image is too dark, while bright part		
		overexposes easily. When this value is small, the image dims.		
		Adjust image hue. There is a default value according to		
Hue		sensitometric feature of the sensor. Generally, it is unnecessary		
		to adjust this value greatly.		
		Adjust image shade. The larger the value is, the deeper the color		
Saturation	n	becomes, and vice versa. This value doesn't affect overall		
		brightness of the image.		
		Adjust image noise. The less the value is, the smaller the noise		
Gain Auto	1	becomes, but image brightness is very dark in dark scene. The		
Cantrace	,	larger the value is, the more brightness will be obtained in dark		
		scene, but image noise becomes more obvious.		
		Set white balance mode, mainly affecting overall hue. It is		
		automatic mode by default.		
		Disabled: any mode is not set.		
		Automatic: set white balance automatically, compensate		
Scene Mo	ode	white balance of different color temperature automatically,		
		and ensure normal image color.		
		 Sunny: threshold value of white balance is set to sunny day mode. 		
		 Night: threshold value of white balance is set to night mode. 		
		Camera image display is set to colorful or black and white mode.		
		Colorful: display colorful image.		
Day/Nigh	t Mode	Automatic: automatically choose to display colorful image or		
Dayringii	· Modo	black white image according to ambient brightness.		
		Black white: display black and white image.		
Backlight Mode		There are several modes:		
		Disabled: no backlight.		
		Backlight: prevent silhouette appearing in dark part of the		
		subject against the light.		
		Wide dynamic: according to ambient brightness, the system		
		reduces brightness of high-brightness area, increases		
		brightness of low-brightness area, and thus displays both		
		areas clearly.		
		Inhibition: the system inhibits brightness of high-brightness		

Parameter	Description	
	area of the image, reduces halo size and thus reduces	
	brightness of the entire image.	
Mirror	Select "On"; the image will be turned over from left to right.	
Flip	Select "On"; the image will be turned over from top to bottom.	

Table 7-12

7.9.2 Audio Set

Step 1 Select "System Config >Video Set>Audio Set".

The system displays "Audio Set" interface, as shown in Figure 7-46.



Figure 7-46

Step 2 Adjust VTO mic volume and beep volume.

7.10 IPC Info

Add IP camera (IPC) info and support max. 32 channels. IPC info will be synchronized with VTH automatically, in order to facilitate VTH monitoring.

Select "System Config > IPC Info". The system displays "IPC Info" interface, as shown in Figure 7-47.



Figure 7-47

7.10.1 Add One IPC

Add IPC info one by one.



Add IPC directly, or add NVR/XVR/HCVR devices to obtain info about the added IPC.

Step 1 Click <a>^.

The system displays "Modify" interface, as shown in Figure 7-48.




Figure 7-48

Step 2 Set parameters and refer to Table 7-13 for details.

Parameter	Description		
IPC Name	Enter IPC/NVR/XVR/HCVR name.		
IP Address	Enter IP address of the connected IPC/NVR/XVR/HCVR.		
Username	Enter the username and password to login WEB interface of		
Password	IPC/NVR/XVR/HCVR.		
Port No.	It is 554 by default.		
It consists of local protocol and Onvif protocol. Please s			
Protocol	according to the protocol supported by the connected device.		
Select from main format and extra format according to needs.			
	Main format: large stream, high definition, large occupied		
Stream	bandwidth, suitable for local storage.		
	Extra format: smooth image, small occupied bandwidth, suitable		
	for low bandwidth network transmission.		
	To connect IPC, it is 1 by default.		
Channel	To connect NVR/XVR/HCVR, it is set to channel no. of IPC on		
	NVR/XVR/HCVR.		

Table 7-13

Step 3 Click "OK" to complete adding.

7.10.2 Delete

Click comera info.

7.10.3 Batch Import

With batch import function, import IPC info into the system.

Click "Import Config", select config file (.csv) and import the file info into the system.

7.10.4 Batch Export

Export and save the present IPC info to the local device, for the sake of future use.

Click "Export Config"; select the path to save config file.

7.11 Fingerprint Manager

Collect, remove fingerprint and remove all fingerprints; import and export fingerprint info.

- NOTE
- Max. 3,000 fingerprints can be collected.
- Fingerprint module has been configured and added to façade layout. Please refer to "7.7.2"
 Facade Layout" for details.

Select "System Config > Fingerprint Manager". The system displays "Fingerprint Manager" interface, as shown in Figure 7-49.



Figure 7-49

7.11.1 Collect Fingerprint

After collection, the fingerprint can be used to open the door.

Step 1 Click "Collect".

The system displays "Fingerprint Info" interface, as shown in Figure 7-50.



Figure 7-50

Step 2 Set "Username" and "Room No.", and click "OK".

The system prompts that "Please collect the fingerprint for three times on the device".

NOTE

"Room No." refers to room no. of VTH.

Step 3 According to voice prompt of VTO, press your finger on fingerprint sensor, and collect the same fingerprint for 3 times.

If WEB interface shows "Collected successfully", it means that the fingerprint is collected successfully and the fingerprint info is displayed in fingerprint info list.

If WEB interface shows "Failed", please collect it again.

7.11.2 Modify Fingerprint Info

Click to modify corresponding username of the fingerprint.

7.11.3 Remove Fingerprint

Click to remove corresponding fingerprint info.

Click "Remove All" to remove all fingerprint info.

7.11.4 Import Fingerprint Info

Import fingerprint info in batches, in order to open the door with a fingerprint.

- Step 1 Click "Fingerprint Import".
- Step 2 Select fingerprint info file (.csv).
- Step 3 Click "Open".

The system prompts "Operation Succeeded", representing successful import.

7.11.5 Export Fingerprint Info

Fingerprint info in the system is exported to local device in the form of Excel, before which the info shall be exported to temporary cache first.

Step 1 Click "Fingerprint Export to Temp".

The system displays the prompt as shown in Figure 7-51. It means that fingerprint info has been imported into browser cache.




Figure 7-51

- Step 2 Click "OK".
- Step 3 Click "Fingerprint Export to Excel".
- Step 4 Select the storage path.

 Save the fingerprint info to local device, for the sake of future use.

7.12 Info Search

Search VTO call history, alarm record and unlock record.

7.12.1 Call History

View VTO call and talk record. Max. 1,024 records can be saved.

Select "Info Search> Call History". The system displays "VTO Call History" interface, as shown in Figure 7-52.

Click "Export Record" to export the VTO call record.



Figure 7-52

7.12.2 Alarm Record

View VTH 8-channel alarm, duress alarm and other alarm records. Max. 1,024 records can be saved.

Select "Info Search> Alarm Record". The system displays "Alarm Record" interface, as shown in Figure 7-53. Click "Export Record" to export the VTO alarm record.



7.12.3 Unlock Record

View unlock records with fingerprint, card, password, remote way and button. Max. 1,000 records can be saved.

Select "Info Search> Unlock Record> VTO Unlock Record". The system displays "VTO Unlock Record" interface, as shown in Figure 7-54.

Click "Export Record" to export the VTO unlock record.



Figure 7-54

7.13 Reboot Device

Reboot the device at WEB interface.

Step 1 Select "Logout > Reboot Device".

The system displays "Reboot Device" interface, as shown in Figure 7-55.

Step 2 Click "Reboot Device", so the device reboots automatically. WEB interface is switched to WEB login interface.




Figure 7-55

7.14 Logout

Log out the WEB interface.

Step 1 Select "Logout > Logout".

The system displays "Logout" interface, as shown in Figure 7-56.

Step 2 Click "Logout". Log out the WEB interface and return to login interface.




Figure 7-56

1. Question: Press the call key; the indicator light turns on, but VTO doesn't call?

Answer: Please confirm validity of this call again.

2. Question: How can I hang up?

Answer: Please press buttons on the VTO, and VTO will send corresponding prompt tone.

3. Question: There is no sound or light, and it doesn't start. How can I deal with it?

Answer: Check whether power supply is normal, and whether socket is in good contact.

4. Question: It prompts that the call is unreachable. How can I deal with it?

Answer: Network failure. Please check whether network cable between this device and extension is inserted in place, and whether VTH is registered at VTO.

5. Question: Voice is too low. How can I deal with it?

Answer: Please adjust VTO volume and VTH talk volume according to actual conditions.

6. Question: The device fails to boot up. How can I deal with it?

Answer: Please check whether power supply of VTO and VTH is normal.

7. Question: VTH has no video or video quality is poor. How can I deal with it?

Answer: VTO WEB interface switches to WVGA video format. Please don't put VTO at places with unideal ray of light or with direct exposure to sunlight.

8. Question: The device fails to unlock. How can I deal with it?

Answer: Please check whether connecting line of VTO access module loosens, and whether electrical control lock breaks down (incorrect wiring, no voltage output or low voltage output).

9. Question: How can I deal with problems that are not confirmed or cannot be solved?

Answer: Please consult professional technical support.

Appendix 1 Technical Parameters

Appendix 1.1 VTO2000A-C-2

Model		VTO2000A-C-2		
System	Main Processor	Embedded microcontroller		
System	Operating System	Embedded LINUX operating system		
	Video Compression Standard	H.264		
Video	Input	1 megapixel CMOS HD camera		
	Night Vision	Support		
	Input	Omnidirectional microphone		
Audio	Output	Built-in speaker		
	Talk	Support two-way audio talk		
Operating	Input	One-button input		
Mode	Lock Status Detection	Support (optional)		
Structure &	Material	Stainless steel		
Installation	Mounting Mode	Surface mounting and flush mounting		
	Protection against Mechanical	IK07		
Protection	Impacts	INO7		
Performance	Protection against Solid	IP54		
l enomiance	Objects and Liquids	11 34		
	Tamperproof	Support		
Network	Ethernet	10M/100Mbps self-adaptive		
Network	Network Protocol	TCP/IP		
	Power Supply	VTNS1006A-2		
	Power Consumption	Working ≤5W		
Specification	Working Temperature	- 30℃~+55℃		
Specification	Relative Humidity	10%∼95%RH		
	Size (Lengthx Width x Height)	110.7mm×118.1mm×42.3mm (including lens case)		
	Weight	0.36kg		

Appendix 1.2 VTO2000A-B/VTO2000A-K/VTO2000A-R /VTO2000A-F

Model		VTO2000A-B	VTO2000A-K	VTO2000A-R	VTO2000A-F
Operation Mode Input		Three-button	14-button	Card reader,	Capacitance
				proximity sensor	sensor
	Power	Standby ≤0.1W;	Standby ≤0.1W;	Standby ≤0.3W;	Standby ≤0.4W;
Spec	Consumption	Working ≤0.45W	Working ≤0.45W	Working ≤0.3W	Working ≤0.4W
	Working	- 40°C∼+60°C	- 40℃~+60℃	- 40°C∼+60°C	- 40°C∼+60°C
	Temperature	- 40 C ~ +60 C	- 40 C~+60 C	- 40 C ~ +60 C	- 40 C/~+60 C
ificati	Relative	10%∼95%RH	10%∼95%RH	10%∼95%RH	10%∼95%RH
on	Humidity	10% ² 95%KH	10%/~95%KH	10%/~95%KH	10%/~95%KH
	Size (Lengthx	110mm×120mm	110mm×120mm	110mm×120mm	110mm×120mm
	Width × Height)	×24.9mm	×29mm	×24.9mm	x32mm
	Weight	0.27kg	0.32kg	0.27kg	0.3kg

Appendix 2 Accessory Specification

Appendix 2.1 Specification of Network Cable

Please select network cable reasonably according to wiring length L_N between VTO and VTH.

Specification of Network Cable	0 <l<sub>N≤50m</l<sub>	50 <l<sub>N≤100m</l<sub>
UTP Cat5e/Cat6: 10 Ohm/100m	Yes	Yes
UTP Cat5e/Cat6: 18.8 Ohm/100m	Yes	No



CAUTION

Please try to ensure that wiring length L_N doesn't exceed 100m.

Appendix 2.2 Specification of Extension Power Cord

Please select suitable extension power cord according to distance $L_{\mathbb{C}}$ between adapter and VTO.

Specification of Extension Power Cord	0 <l<sub>C≤30m</l<sub>	30 <l<sub>C≤100m</l<sub>
20AWG	Yes	No
18AWG	Yes	Yes
17AWG	Yes	Yes



CAUTION

Before power on, please check whether positive and negative poles of extension power cord are wired correctly; avoid reverse connection.

Appendix 2.3 Specification of Embedded Box

Model	Specification of Embedded Box
2-wire Modular VTO with Single Module	Flush mounting box 115mm×115mm×57mm
2-wire Modular VTO with 2 Modules	Flush mounting box 237mm×125mm×50mm
2-wire Modular VTO with 3 Modules	Flush mounting box 349mm×125mm×50mm